



Wood Filler

- Water based
- Quick drying
- Low odour
- Flexible and stainable
- Shrink and crack resistant
- Suitable for interior and exterior use
- Wide range of colours available



USAGE

Interior and exterior

COVERAGE

As required

APPLICATION

Painter's knife

DRYING TIME

Min 2hrs
Depending on depth

TOOL CLEANING

Water

Product use

Liberon Wood Filler is a ready to use, water based, multi-purpose filler for filling and repairing surface damage in wood. Quick drying, shrink and crack resistant, it is easily sanded and may be screwed and nailed. The low odour, easy to use Wood Filler is suitable for both interior and exterior use and may be stained, varnished, waxed or painted. Wood Filler is available in natural and a selection of wood shades. To obtain other shades Liberon Wood Fillers may be blended together.

Preparation

Ensure the area to be repaired is clean, dry and free from dust. Select the colour which is closest to the colour of the wood, adapting your choice if dying the wood.

Application

Apply using a Liberon plastic scraper or suitable filling knife. For best results resist overspreading the repair area, but leave sufficient over fill to enable thorough sanding. Allow to dry thoroughly – two hours or more depending on the depth of the repair. Then sand, colour and finish as required.

Small holes may be filled in one operation. Deeper holes should be built up in layers.

Important: always test products first on an inconspicuous area to check colour compatibility and end results. Wood Filler may accept dyes/stains differently to surrounding wood. When using outdoors protect with a suitable exterior grade finish.

Packaging

Wood Filler is available in 125 ml containers.

Colours

Natural, Antique Pine, Dark Oak, Mahogany.

Health and Safety

The use of gloves is recommended when applying this product. Do not apply below 10°C and store frost-free. Keep out of the reach of children.